

# röyale

#### THE PERFECT COMBINATION OF HYGIENE AND AESTHETICS THAT ENSURES A SAFE & BEAUTIFUL HOME FOR YOU.

Royale Health Shield, the first paint in India with Silver Ion Technology. The technology is recommended\* by the Indian Medical Association. It kills 99%<sup>#</sup> Infection causing bacteria on the walls. It also absorbs Formaldehyde which is a common source of indoor air pollution.

KILLS 99% <sup>#</sup> BACTERIA	On Walls within 2 hours of exposure.
SILVER ION TECHNOLOGY	Technology Recommended* by the Indian Medical Association.
HELPS PURIFY AIR	Neutralizes Formaldehyde - a common source of indoor air pollution.
BEST-IN-CLASS FINISH	Gives a luxurious finish to your walls.
EXCELLENT STAIN RESISTANCE	Wipes away toughest of stains



## röyale

### LUXURY EMULSION

#### THE ANTI-BACTERIAL PAINT

APPROVED BY WORLD RENOWNED TESTING & REGULATORY ORGANISATIONS.

Its revolutionary technology kills 99%<sup>\*</sup> bacteria on your walls. The paint that protects and nurtures your home.



Indicates that it kills 29 species of disease causing bacteria.





IDICATES GREEN SEAL GREEN ASSURANCE.

EAL AS RECOMM E. INDIAN I ASSOC



\* Fomite Infections (bacteria) can spread through infected walls among other indoor surfaces in homes and offices. \*Royale Health Shield with Silver Ion Technology, within 2 hours of exposure kills 99% bacteria on walls. For complete disclaimerand more information refer to our website www.asianpaints.com/healthshield

#### **Essential Whites & Neutrals**



#### Warm Shades



#### **Fresh Hues**



#### Cool Tones



#### **Recommended Combinations**



Green Beret 7838

Warm Khaki-N K206

#### **Recommended Combinations**



Retro Blue-N 9680

Misty Moon-NK102

#### DIRECTIONS FOR USE



Sand the surface with Asian Paints TruStar Sand Paper No. 180 to remove loose particles or dirt and wipe clean.



Apply 1 coat of Royale Wall Basecoat and allow drying for 4-6 hours.



Smoothen the surface with coats of TruCare Acrylic Wall Putty. Allow drying for 4-6 hours. Sand the surface with Asian Paints TruStar Sand Paper No. 180 and wipe clean.



Apply another coat of Royale Wall Basecoat and allow drying for 4-6 hours. Sand the surface with Asian Paints TruStar Sand Paper No. 320 or 400 and wipe clean.



Thin 1 litre Royale Health Shield with 400-500 ml of water.



Apply 2-3 coats of Royale Health Shield with a 4-6 hour gap between each coat. For best results, use Asian Paints TruCare Elite Roller 1000 for application.





Marketed by: Asian Paints Ltd., 6A Shantinagar, Santacruz (E), Mumbai 400 055.

For more information on painting and colour selection, log on to www.asianpaints.com/healthshield or call us at: 1800-209-5678

Disclaimer: No part of this material may be reproduced or copied in any form or by any means (graphics, electronic or mechanical, including photocopying, recording, taping or information storage retrieval systems) or reproduced in any disc, tape, perforated media or other information storage device, etc. without written permission of Asian Paints Ltd. All disputes are subject to Mumbai jurisdiction only.



Re

12

V. No. 3/S	
01/2020	

Free Sample. Not for <u>Ret</u>ail Sale.